

Issue 1

<http://www.thehygienecompany.com/>

Tel: 0845 370 0030

E-mail: info@thehygienecompany.com



HYGIENE MONITOR OPERATOR GUIDE

HYGIENE MONITOR OPERATOR GUIDE

USING THE HYGIENE MONITOR

When entering* your facilities, simply insert your **Operator Card** into the Hygiene Monitor:



*In some cases, you may have to reset the monitor by inserting your card upon leaving the facilities.



PLEASE NOTE!

The **Operator Card** should be inserted with the bronze chip facing the wall.

Allow the **Hygiene Monitor** to register the card. When complete, the **Hygiene Monitor** will beep and will display '**done**'. You can then remove your card.

Some cards have a clock in/out function. If this is the case, you may be asked to insert the card when you leave the facilities.

WHAT TO DO IF YOUR CARD DOES NOT REGISTER

The bronze chip on an **Operator Card** does wear out over time. If you receive an error message, it may be that you need to contact your line manager for a new operator card to be issued. Before you do so, try inserting the card a second time as occasionally small pieces of debris may have stopped the chip from sitting properly in the card reader.



Cox Green
Church Road
Ramsden Heath
Essex
CM11 1PS
United Kingdom



0845 370 0030 /



0800 019 7102 /



07956 260417



0845 370 0040



info@thehygienecompany.com
www.thehygienecompany.com



[thehygienecompany](https://www.facebook.com/thehygienecompany)